

# 3

HOW TO GUIDES BY NEIL SULLIVAN & SONS

# FINISHING



**E.**

Help reduce the risk of the concrete cracking by making control joints with a groover.

**F.**

Make patterns on the surface by sweeping over with a broom. This creates traction to avoid a slippery surface.



**G.**

Leave the concrete for 28 days to cure. The concrete can be sealed to encourage it to cure and prevent cracks and discoloration.

**H.**

Regular maintenance will help the concrete stay in good condition. Wash with soap and water and re-seal to prevent any damage through regular use.

